```
'--------Title--------

' File......servo4.pbp
' Started....6/1/05
' Microcontroller used:  Microchip Technology 16F88
'                        microchip.com
' PicBasic Pro Code: micro-Engineering Labs, Inc.
'                    melabs.com

'--------Program Desciption--------

' Three momentary switches rotate the servo into three
' different positions: left, center, and right.
' Discussion about basic servo pulse control may be found
' at www.seattlerobotics.org/guide/servos.html or
' www.geocities.com/hobby_robotics/was.htm

'----------Related Lesson----------

' servo4.pbp is used in the lesson PIC PROGRAMMING 3 SERVOS at:
' http://cornerstonerobotics.
org/curriculum/lessons_year2/erii13_pic_programming3_servos.pdf

'------------Comments--------------

' WITH THE PIC16F88, MAKE SURE TO HAVE SEPARATE +5V
' POWER SOURCES FOR THE PIC AND THE SERVO. MAKE SURE TO
' HAVE A COMMON GROUND BETWEEN THE PIC AND SERVO.  We use one 9V
' battery and two 78L05 voltage regulators.  See
' discussion about voltage regulators at:
' http://cornerstonerobotics.
org/curriculum/lessons_year2/erii3_diodes_power_supplies_voltage_reg.pdf

' Also, initialize the state of PORTB as LOW
' since that will set the correct polarity of the
' PULSOUT statement.  See PULSOUT in PicBasic Pro
' Compiler manual by microEngineering Labs, Inc.
' Look around page 121 in the PicBasic Pro Compiler Manual

'-----------Connections-----------

'       PIC16F88 Pin            Wiring
'       ---------            ----------
'           RB0             Servo Control Wire
'           RB1             Momentary Switch 1
'           RB2             Momentary Switch 2
'           RB3             Momentary Switch 3
'           Vdd             +5 V
'           Vss             Ground
'           MCLR            4.7K Resistor to +5 V

'---------Revision History---------

' 11/14/07 Add 16F88 oscillator initialization
' 11/27/07 Add power supply warning and
```

```
'          changed title from servo1.pbp to servo4.pbp

'------------Variables-------------

     i      VAR     BYTE        ' BYTE for counter, i

'------Switch Connection Pins------

     switch1   VAR PORTB.1      ' Labels PORTB.1 as switch1
     switch2   VAR PORTB.2      ' Labels PORTB.2 as switch2
     switch3   VAR PORTB.3      ' Labels PORTB.3 as switch3

'----------Initialization----------

    TRISB = %00001110

    PORTB = %00000000           ' Equivalent to: PORTB = 0
                                ' Sets all PORTB pins to LOW(0 volts)
                                ' Make certain to include this
                                ' initialization as it sets the
                                ' proper polarity of pulses in
                                ' the PULSOUT command.

    OSCCON = $60                ' Sets the internal oscillator in the
                                ' 16F88 to 4 MHz

'-------------Main Code------------

start:

    IF switch1 = 1 THEN GOSUB left
                                ' If the switch on PORTB.1 is pushed,
                                ' PORTB.1 becomes high (+5 volts) and
                                ' the comparison is true; the program
                                ' jumps to the subroutine labeled left.

    IF switch2 = 1 THEN GOSUB center
                                ' If the switch on PORTB.2 is pushed,
                                ' PORTB.2 becomes high (+5 volts) and
                                ' the comparison is true; the program
                                ' jumps to the subroutine labeled center.

    IF switch3 = 1 THEN GOSUB right
                                ' If the switch on PORTB.3 is pushed,
                                ' PORTB.3 becomes high (+5 volts) and
                                ' the comparison is true; the program
                                ' jumps to the subroutine labeled right.

    GOTO start                   ' Jumps to label loop

    END                  ' Place subroutines after END

'Subroutines:

left:
```

```
    FOR i = 1 TO 10      ' Send left signal 10 times

    PULSOUT 0,100        ' Pulse Width:
                         ' Sends a pulse out on pin RB0 for 1.0 mS.
                         ' The period,(100) is multiplied by the
                         ' increment for a 4 MHz oscillator (10 uS)
                         ' to get a pulse out time of 1.0 mS.
                         ' To get the full range of your
                         ' servo, you may have to decrease the period
                         ' to less than 100, being careful not to go too
                         ' low thereby forcing the servo to stop
                         ' mechanically against the internal mechanical
                         ' stops.

    PAUSE 20 - 1         ' Pulse Interval:
                         ' Pause 20 ms less pulse width (1.0 ms)
                         ' This equation keeps the period of
                         ' the servo pulse a constant 20 ms, HIGH
                         ' for 1.0 ms and LOW for 19 ms = 20 ms.

    NEXT i               ' Go back to the FOR statement and do
                         ' next count, i

    LOW 1                ' Bring switch1,(RB1),state to LOW to prevent
                         ' the pin's voltage from floating

    RETURN               ' Returns execution to statement following
                         ' GOSUB left command
center:

    FOR i = 1 TO 10      ' Send center signal 10 times

    PULSOUT 0,150        ' Pulse Width:
                         ' Sends a pulse out on pin RB0 for 1.5 mS.
                         ' The period,(150) is multiplied by the
                         ' increment for a 4 MHz oscillator (10 uS)
                         ' to get a pulse out time of 1.5 mS.

    PAUSE 20 - 15/10     ' Pulse Interval:
                         ' Pause 20 ms less pulse width (15/10 = 1.5 ms)
                         ' This equation keeps the period of
                         ' the servo pulse a constant 20 ms, HIGH
                         ' for 1.5 ms and LOW for 18.5 ms = 20 ms.
                         ' Note: In PicBasic Pro, numbers and variables
                         ' must always be non-negative integers.
                         ' 20 - 1.5 is not permissible since 1.5 in not
                         ' an integer.  To get around the problem, use
                         ' integers 15/10 to create the same value.

    NEXT i               ' Go back to the FOR statement and do
                         ' next count, i

    LOW 2                ' Bring switch2,(RB2),state to LOW to prevent
                         ' the pin's voltage from floating
```

```
    RETURN                  ' Returns execution to statement following
                            ' GOSUB center command
right:

    FOR i = 1 TO 10         ' Send right signal 10 times

    PULSOUT 0,200           ' Pulse Width:
                            ' Sends a pulse out on pin RB0 for 2.0 mS.
                            ' The period,(100) is multiplied by the
                            ' increment for a 4 MHz oscillator (10 uS)
                            ' to get a pulse out time of 2.0 mS.
                            ' To get the full range of your
                            ' servo, you may have to increase the period
                            ' to more than 200, being careful not to go too
                            ' high thereby forcing the servo to stop
                            ' mechanically against the internal mechanical
                            ' stops.

    PAUSE 20 - 2            ' Pulse Interval:
                            ' Pause 20 ms less pulse width (2 ms)
                            ' This equation keeps the period of
                            ' the servo pulse a constant 20 ms, HIGH
                            ' for 2 ms and LOW for 18 ms = 20 ms.

    NEXT i                  ' Go back to the FOR statement and do
                            ' next count, i

    LOW 3                   ' Bring switch3,(RB3),state to LOW to prevent
                            ' the pin's voltage from floating

    RETURN                  ' Returns execution to statement following
                            ' GOSUB right command
```