```
'----Title-----
' File.....active_low.pbp
' Started....7/12/09
' Microcontroller used: Microchip Technology 16F88
                      microchip.com
' PicBasic Pro Code: micro-Engineering Labs, Inc.
                   melabs.com
'----Program Desciption-----
' PIC turns on an LED when a switch is pressed.
' The switch is wired as an active low.
'-----Related Lesson-----
' active_low.pbp is used in the lesson Source and Sink Outputs /
' Active High and Low Inputs at:
' http://www.cornerstonerobotics.
org/curriculum/lessons_year2/erii19_active_high_active_low.pdf
'----PIC Connections-----
       16F88 Pin
                           Wiring
                         150 Ohm resistor to LED to GND
       RB0
                         Active low switch
       RB1
                         4.7K Resistor to +5 V
       RB4
       RB5
                         Ground
                          +5 V
       RB14
'-----Variables-----
   switch1 VAR PORTB.1 ' Labels PORTB.1 as switch1
'-----Initialization-----
   TRISB = %11111110
                          ' Sets up RBO pin of PORTB as an output
                          ' and pins RB7-RB1 of PORTB as inputs
   OSCCON = $60
                          ' Sets the internal oscillator in the
                          ' 16F88 to 4 MHz
'-----Main Code-----
start:
   IF switch1 = 0 THEN led_on ' If the switch on PORTB.1 is pushed,
                              ' PORTB.1 becomes LOW (0 volts) and
                              ' the comparison is true, so the program
                              ' jumps to the label led_on.
   LOW 0
                              ' When the comparison is false, the program
                              ' proceeds to the statement after the
                              ' IF..THEN command, in our case, LOW 0.
```

Page 1 of 2 5/24/2013 5:02 PM

END

Page 2 of 2 5/24/2013 5:02 PM