

' -----Title-----

' File.....bend_sensor1.pbp
' Started....3/4/08
' Microcontroller used: Microchip Technology PIC16F88
' microchip.com
' PicBasic Pro Code: micro-Engineering Labs, Inc.
' melabs.com

' -----Program Description-----

' Program converts analog input from a bend sensor
' into a change in the position of a hobby servo.

' -----Comments-----

' Servo used is a Futaba S3003 standard servo.
' The bend or flex sensor is Jameco #150551,
' 0 degrees - 10K ohms, 90 degrees - 30-40K ohms.

' -----PIC Connections-----

' 16F88 Pin	' Wiring
' -----	' -----
' RA0	' Center bend sensor voltage divider
' RA4	' LCD Register Select(RS)
' RB0	' Servo Control Wire (Futaba white wire)
' RB3	' LCD Enable(E)
' RB4	' LCD (DB4)
' RB5	' LCD (DB5)
' RB6	' LCD (DB6)
' RB7	' LCD (DB7)

' See schematic for the other usual PIC connections

' -----LCD Connections-----

' LCD Pin	' Wiring
' -----	' -----
' 1	' Ground(Vss)
' 2	' + 5v(Vdd)
' 3	' Center of 20K Pot(Contrast)
' 4	' RA4(Register Select,RS)
' 5	' Ground(Read/Write,R/W)
' 6	' RB3(Enable)
' 7	' No Connection(DB0)
' 8	' No Connection(DB1)
' 9	' No Connection(DB2)
' 10	' No Connection(DB3)
' 11	' RB4(DB4)
' 12	' RB5(DB5)
' 13	' RB6(DB6)
' 14	' RB7(DB7)

' -----Revision History-----

' -----Constants/Defines-----

```
' To free up AN0 (Pins RA0) for an analog input,
' the default LCD data lines, DB4-DB7,
' function was removed from RA0 - RA3.
' They are relocated to PORTB.4 - PORTB.7 (RB4-RB7)
' using the LCD DEFINE statements below. All other
' default LCD pins and functions are left unchanged.
```

```
DEFINE LCD_DREG PORTB           'Sets PORTB as LCD data port
DEFINE LCD_DBIT 4                'Start data connections to bit 4

DEFINE ADC_BITS 10               'Sets the number of bits in
                                'the result to 10
```

' -----Variables-----

```
bend    VAR     WORD          'Word for bend sensor voltage divider
servo   VAR     WORD          'Word to store calculated servo value
```

' -----Initialization-----

```
ANSEL = %00000001  'Leaves AN0 in analog mode, but
                    'changes other analog bits to digital.
                    'See table below.
```

Analog Bit	Analog or Digital	PIC16F88 Pin
AN0	Analog	RA0
AN1	Digital	RA1
AN2	Digital	RA2
AN3	Digital	RA3
AN4	Digital	RA4
AN5	Digital	RB6
AN6	Digital	RB7

```
ADCON1 = %10000000          'Right justifies 10-bit value of bend
                            'in 16-bit WORD. Adds "0" in the
                            '6 Most Significant bits of the Word,
                            'shifting the 10-bit value of bend to
                            'the right.

OSCCON = $60                 'Sets the internal oscillator in the
                            '16F88 to 4 MHz

PORTB = 0                     'A must for the PULSOUT command,
                            'establishes proper polarity for servo
```

' -----Main Code-----

```
PAUSE 1000                  'Pause to allow LCD to setup
```

```
start:
```

```
ADCIN 0, bend                'Read analog voltage on AN0 and
                                'convert to 10-bit digital value
```

```
' and store as bend.

LCDOUT $FE,1,"bend = ", DEC bend
    'Clears LCD screen, displays
    '"bend = " and the 10-bit
    'value of bend

' The range of bend values is from about 350 to 620. Use the
' following formula to convert bend values to the range of
' the servo pulses, 60 - 220.

    servo = (bend/8)*5-160      'Convert bend value to servo
                                'PULSOUT value

IF servo >220 THEN servo = 220
    'Create upper threshold to protect servo

IF servo <60 THEN servo = 60 'Create lower threshold to protect servo

LCDOUT $FE,$C0,"servo =", DEC servo
    'LCD jumps to beginning of second
    'line and displays "servo = "
    'and the 10-bit value of servo.

PULSOUT 0,servo
    'Send position signal to RB0. Pulse out
    'time varies from 2.2 msec to 0.6 msec.

PAUSE 20
    'Pause 20 msec, gives proper period for
    'pulses to servo

GOTO start
    'Start over again

END
```