

```

/*-----Title-----

File: servo2.ino
Started: 11/11/13
Program Description: Control a servo position using a potentiomet
For servo signal waveforms, see:
http://cornerstonerobotics.org/arduino/Servo%20Signals.pdf
*/
//-----Initializations-----

int servo = 9; // Give pin 9 a name (servo).
int potpin = A0; // Give analog pin A0 the name potpin.
int x; // Variable to read the value from the analog p

void setup()
{
}
//-----Main Code-----

void loop()
{
  // Read the input on analog pin A0 (value between 0 and 1023):
  x = analogRead(potpin);
  // Re-map the value of x, (which goes from 0-1023)
  // to a value from 800 to 2300. The range of servo rotation is
  // set by changing these two numbers.
  // Syntax: map(value, fromLow, fromHigh, toLow, toHigh)
  x = map(x, 0, 1023, 800, 2300);
  // Create HIGH pulse between 800 microseconds (0.8 ms) and
  // 2300 microseconds (2.3 ms) long:
  digitalWrite(servo, HIGH);
  delayMicroseconds(x); // Wait x microseconds (800-2300 microsec
  // Create LOW pulse:
  digitalWrite(servo, LOW);
  delay(20); // Wait 20 ms
}

```