```
'-----Title-----
' File.....16F877A_step_mot_one_revolution.pbp
' Started....2/14/09
' Microcontroller used: Microchip Technology 16F877A
                       microchip.com
' PicBasic Pro Code: micro-Engineering Labs, Inc.
                   melabs.com
' Stepper Motor Used: Jameco #237623
' (#237623 - 4.8V, 1500mA, 1.8 Degree Step Angle or 200 Steps/Revolution)
'-----Program Desciption-----
' Program drives stepper motor to rotate one revolution clockwise in 1 sec
' then one revolution counter-clockwise in 1 sec then to stop.
'-----Schematic-----
' See schematic at:
' http://cornerstonerobotics.org/schematics/pic_16f877a_step_mot1.pdf
'-----Related Lesson-----
' See the lesson Stepper Motor Control with a PIC at:
' http://www.cornerstonerobotics.
org/curriculum/lessons_year2/erii_stepper_motor.pdf
' Lesson also includes a section on how to figure out how to hook
' up a stepper motor with six leads when a data sheet for the
' motor is unavailable.
'-----Comments-----
' WITH THE PIC16F877A, BE CERTAIN TO HAVE SEPARATE POWER
' SOURCES FOR THE PIC AND THE STEPPER MOTOR. MAKE SURE
' TO HAVE A COMMON GROUND BETWEEN THE PIC AND MOTOR.
'----New PicBasic Pro Command----
' The PicBasic Pro Compiler Manual is on line at:
' http://www.microengineeringlabs.com/resources/index.htm#Manuals
' LOOKUP Index, [Constant{,Constant...}], Var
' The LOOKUP statement can be used to retrieve values from a table of 8-
' bit constants. If Index is zero, Var is set to the value of the first
' Constant. If Index is one, Var is set to the value of the second
' Constant. And so on. If Index is greater than or equal to the number
' of entries in the constant list, Var remains unchanged.
' Look around page 102 in the PicBasic Pro Compiler Manual
'-----PIC Connections-----
    PIC16F877A Pin
                             Wiring
                          -----
       _____
           RB0
                         Stepper Motor Control Wire 1
```

```
RB1
                           Stepper Motor Control Wire 2
                          Stepper Motor Control Wire 3
           RB2
                           Stepper Motor Control Wire 4
           RB3
                           +5 V
           Vdd
           Vss
                           Ground
           MCLR
                           4.7K Resistor to +5 V
'-----Variables-----
                       BYTE ' BYTE for counter variable, i
WORD ' WORD for variable Delay
BYTE ' Motor Pulse Sequence (1,2,3,4,1,...)
               VAR
   Delay
               VAR
   PulseSeq
               VAR
                                ' or (4,3,2,1,4,..)
'-----Initialization-----
   TRISB = %00000000 ' Sets all PORTB pins to output
'-----Main Code-----
   PulseSeq = 0
                          ' Sets PulseSeg to 0
' Rotates stepper motor 1 revolution in 1 second CW then CCW
   Delay = 5
                           ' 1sec / 200 steps = 5ms delay
' Clockwise rotation:
                        ' For Jameco #237623 stepper motor,
   FOR i = 1 TO 200
                          ' 200 steps = 1 rev
       GOSUB CW StepMtr
   NEXT i
   PAUSE 500
                           ' Pause 500 ms before CCW rotation begins
' Counter-clockwise rotation:
   FOR i = 1 TO 200
                          ' For Jameco #237623 stepper motor,
                            ' 200 steps = 1 rev
       GOSUB CCW_StepMtr
   NEXT i
                            ' Equivalent to PORTB = %00000000
   PORTB = 0
                            ' All coils are turned off.
   END
CW_StepMtr:
                           ' CW_StepMtr subroutine
   IF PulseSeq >= 4 THEN
      PulseSeq = 1 ' Restart the 1,2,3,4 sequence at 1
```

```
ELSE
       PulseSeq = PulseSeq + 1
                             ' Increment PulseSeq
                            ' to next step in the sequence
    ENDIF
' Send the correct signal to PORTB
' PulseSeq value 0, 1, 2, 3, or 4
    LOOKUP PulseSeq, [0, 8, 4, 2, 1], PORTB
                             If PulseSeq = 0, PORTB = 0 (%00000000)
                            ' If PulseSeq = 1, PORTB = 8 (%00001000)
                             ' If PulseSeq = 2, PORTB = 4 (%00000100)
                             ' If PulseSeq = 3, PORTB = 2 (%00000010)
                             ' If PulseSeq = 4, PORTB = 1 (%00000001)
                            ' Pause 5ms
    PAUSE Delay
    RETURN
CCW_StepMtr:
                            ' CCW_StepMtr subroutine
    IF PulseSeq <= 1 THEN</pre>
            PulseSeq = 4 ' Restart the 4,3,2,1 sequence at 4
        ELSE
            PulseSeq = PulseSeq - 1
                             ' Decrementing PulseSeq
                             ' to next step in the sequence
        ENDIF
    LOOKUP PulseSeq, [0, 8, 4, 2, 1], PORTB
                             If PulseSeq = 4, PORTB = 1 (%00000001)
                              If PulseSeq = 3, PORTB = 2 (%00000010)
                             ' If PulseSeq = 2, PORTB = 4 (%00000100)
                             ' If PulseSeq = 1, PORTB = 8 (%00001000)
                             ' If PulseSeq = 0, PORTB = 0 (%00000000)
    PAUSE Delay
                            ' Pause 5ms
    RETURN
```

Page 3 of 4 2/14/2009 10:57 AM

C:\Documents and	l Settings\Dad\Desktop\mr	k\16F877A_step_mot_	one_revolution.pbp
------------------	---------------------------	---------------------	--------------------

Page 4 of 4 2/14/2009 10:57 AM